

Transparency Service Agreement Condition Monitoring Compatibility List

Information
for TRUMPF
service and sales

Machine types (technology, fiber or CO ₂)		Transparency Service Agreement	
TruLaser	fiber	L46/ L88 – TruLaser 1030 fiber L72/L82 – TruLaser 2030 fiber L49 - TruLaser 3030 fiber L50 - TruLaser 3040 fiber L66 - TruLaser 3060 fiber L75 - TruLaser 3030 PE fiber L79 - TruLaser 3040 fiber L41 - TruLaser 5030 fiber L47 - TruLaser 5040 fiber L56 - TruLaser 5030 fiber	L57 - TruLaser 5040 fiber L68 - TruLaser 5030 fiber L69 - TruLaser 5040 fiber L76 - TruLaser 5030/5040/5060 fiber L78 - TruLaser 8000 fiber L81 - TruLaser 3030/3040/3060 fiber L26 - TruLaser 7030 Center
	CO ₂	L22 – TruLaser 1030 L20 - TruLaser 3030, 3030 LE L32 - TruLaser 3040 L55 - TruLaser 3030 Prime Edition L70 - TruLaser 3040 Prime Edition L77 - TruLaser 3030 Basic Edition L61 - TruLaser 7030	L62 - TruLaser 7040 L63 - TruLaser 8000 L52 - TruLaser 5030 L53 - TruLaser 5040 L54 - TruLaser 5060
TruMatic	fiber	K07 - TruMatic 1000 fiber K09 - TruMatic 3000 fiber K06 - TruMatic 6000 fiber	
	CO ₂	K05 - TruMatic 6000 K02 - TruMatic 7000 K08 - TruMatic 7000	
TruPunch	---	S05 - TruPunch 1000 S18 - TruPunch 2000 S11 - TruPunch 3000 S12 - TruPunch 5000 S19 - TruPunch 1000 S20 - TruPunch 3000	
TruBend	---	B23 - TruBend 5000 B28 - TruBend 7000 ----- B03 - TruBend 5000 B19 - TruBend 7000 B06 - TruBend Cell 7000	
TruLaser Tube	fiber	T10 - TruLaser Tube 3000 fiber T06 - TruLaser Tube 5000 fiber T07 - TruLaser Tube 7000 fiber	
	CO ₂	T05 - TruLaser Tube 5000 T08 - TruLaser Tube 5000 T02 - TruLaser Tube 7000 T03 - TruLaser Tube 7000	
TruLaser Weld	---	---	
<p>Most of the machine types listed above can be connected if the installation date is 2012+ and if they have HMI version ≥ MMC200X_V04.00.</p>			

